

```
1 NAME = "Zarin Saima","Juaria Tashin"
2 ID = "24141186"
3 COLLABORATORS_ID = "23241054"
```

## ❖ Necessary library import

```
1 import numpy as np
2 from skimage import io, color, exposure , transform
3 import matplotlib.pyplot as plt
```

## ❖ Task 1 - Basic Image Operation

import your image or any photo taken by you (sample.jpeg) as a numpy array, save it in the variable I .

A picture taken from your phone of any scenery/streets/building is better.

remember your image name MUST be sample.jpeg .

Make sure the height and the width of the image is **smaller than 1000 pixels**.


```
1 I = io.imread("sample.jpeg") # Replace None with appropriate function call line
2 height, width, nchannels = I.shape
3
4 # find the height and the width of the image
5 H = height # should contain height
6 W = width # should contain width
7 print("Height is", H)
8 print("Width is", W)
9
10 ### BEGIN SOLUTION
11 if H > 1000 or W > 1000:
12     scale_factor = min(1000 / H, 1000 / W)
13     I_rescaled = transform.rescale(I, scale_factor, anti_aliasing=True, channel_axis=-1)
14     img_resized = (I_rescaled* 255).astype(np.uint8)
15     H, W = I.shape[:2]
16     print("Rescaled image to height:", H, "and width:", W)
17 io.imshow(I)
18 ### END SOLUTION
```

→ Height is 2048  
Width is 1532  
Rescaled image to height: 2048 and width: 1532  
<matplotlib.image.AxesImage at 0x7844f4dd2050>



```
1 # Normalize the image so that the gray scales are between 0 and 1. Save it to I and display the image
2 print("Data type of the image before normalization:", I.dtype)
3
4 # Convert to float if necessary
5 if I.dtype == np.uint8:
6     I = I.astype(np.float32) # Convert to float32
7 ### BEGIN SOLUTION
8 I = I / 255.0
9 io.imshow(I)
10 ### END SOLUTION
```

→ Data type of the image before normalization: uint8  
<matplotlib.image.AxesImage at 0x7844f4cbe7d0>



```
1 #Increase the brightness of the image without changing the contrast.
2 # Save the resulting image in I_bright and display it.
3 I_bright = I + 0.2
4
5 ### BEGIN SOLUTION
6 I_bright = np.clip(I_bright, 0, 1)
7 io.imshow(I_bright)
8 ### END SOLUTION
```

→ <matplotlib.image.AxesImage at 0x7844f4d559f0>



```
1 # Decrease the brightness of the image without changing the contrast.
2 # Save the resulting image in I_dark and display it
```

```

2 # Save the resulting image in I_dark and display it.
3 I_dark = I - 0.2
4
5 ### BEGIN SOLUTION
6 I_dark = np.clip(I_dark, 0, 1)
7 io.imshow(I_dark)
8 ### END SOLUTION

```

☞ <matplotlib.image.AxesImage at 0x7844f4bdc5e0>




```

1 # Multiply the three channels of image I with three DIFFERENT numbers between 0.3 and 3
2 # Save the resulting image in I_tint and display it.
3 # The resulting image should have some color shift
4 I_tint = np.zeros(I.shape)
5 I_tint.shape
6 # HINT:
7 # I_tint = np.zeros(I.shape)
8 # I_tint[:, :, 0] = ..... I[:, :, 0].....
9 # .....
10
11 ### BEGIN SOLUTION
12
13 I_tint[:, :, 0] = I[:, :, 0] * 0.5 # factor 0.5(For red channel)
14 I_tint[:, :, 1] = I[:, :, 1] * 1.5 # factor 1.5(For green channel)
15 I_tint[:, :, 2] = I[:, :, 2] * 2.0 # factor 2.0(For blue channel)
16
17 # Clip values to be between 0 and 1 to avoid overflow
18 I_tint = np.clip(I_tint, 0, 1)
19
20 # Display the tinted image
21 io.imshow(I_tint)
22 ### END SOLUTION


```

```
↳ <matplotlib.image.AxesImage at 0x7844f4c650f0>
```



```
1 # Convert the image into a grayscale image.  
2 # Save it to I_gray and display it  
3 I_gray = color.rgb2gray(I)  
4  
5 ### BEGIN SOLUTION  
6  
7 plt.imshow(I_gray, cmap='gray')  
8 ### END SOLUTION
```

```
↳ <matplotlib.image.AxesImage at 0x7844f4aaab30>
```




```
1 # Display the negative of the grayscale image  
2  
3 ### BEGIN SOLUTION  
4 I_neg = 1 - I_gray  
5  
6 plt.imshow(I_neg, cmap='gray')  
7 plt.axis('off')  
8 plt.show()  
9  
10 ### END SOLUTION
```

→



```
1 # Artificially degrade the **grayscale image** by reducing its contrast
2 # You can do so by rescaling the gray values and concentrating them in a narrow range,
3 # say between 0.3 and 0.6.
4 # Save the image as I_degraded and display it
5 # HINT: SEE lec-4-demo-codes
6
7 I_degraded = exposure.rescale_intensity(I_gray, in_range=(0, 1), out_range=(0.3, 0.6))
8
9
10 ### BEGIN SOLUTION
11
12 plt.imshow(I_degraded, cmap='gray')
13 ### END SOLUTION
```

→ <matplotlib.image.AxesImage at 0x7844f4b6a410>



```
1 import numpy as np
2
3 def piecewise_contrast_stretch(I_gray, r1, r2, s1, s2):
4     """
5         Perform piecewise linear contrast stretching on a grayscale image.
6
7     Parameters:
8         - I_gray: Input grayscale image, normalized between 0 and 1.
9         - r1: Lower threshold for stretching.
10        - r2: Upper threshold for stretching.
11        - s1: Output value corresponding to r1.
12        - s2: Output value corresponding to r2.
13
14    Returns:
15        - I_stretched: Contrast-stretched grayscale image.
```

```

16 """
17 # Initialize the output image with the same shape as the input image
18 I_stretched = np.zeros_like(I_gray)
19
20 # Apply piecewise linear transformations
21 # For values less than r1
22 I_stretched[I_gray < r1] = (s1 / r1) * I_gray[I_gray < r1]
23
24 # For values between r1 and r2
25 mask_between_r1_r2 = (I_gray >= r1) & (I_gray <= r2)
26 I_stretched[mask_between_r1_r2] = ((s2 - s1) / (r2 - r1)) * (I_gray[mask_between_r1_r2] - r1) + s1
27
28 # For values greater than r2
29 I_stretched[I_gray > r2] = ((1 - s2) / (1 - r2)) * (I_gray[I_gray > r2] - r2) + s2
30
31 return I_stretched
32


```

```

1 # To test your implementation, contrast strech the degraded image I_degrade
2 r1 = 0.3
3 r2 = 0.6
4 s1 = 0.2
5 s2 = 0.8
6 I_stretched = piecewise_contrast_stretch(I_degraded, r1, r2, s1, s2)
7 io.imshow(I_stretched)
8
9
10

```

→ <matplotlib.image.AxesImage at 0x7844d146f370>



## ▼ Task 2 - Histogram and Equalization

```


1 import matplotlib.pyplot as plt
2 from skimage import io, exposure
3
4 plt.figure(figsize=(12, 6))
5 plt.imshow(I)
6 plt.title("Original RGB Image")
7 plt.axis('off')
8 plt.show()
9
10
11 plt.figure(figsize=(10, 5))
12 plt.subplot(2, 2, 1)
13
14 #colors and titles for each channel

```


```
15 channels_clrs = ('red', 'green', 'blue')
16 channels_lbls = ('Red Channel', 'Green Channel', 'Blue Channel')
17
18
19 for channel_index, channel_color in enumerate(channels_clrs):
20
21     hist_values, pixel_bins = exposure.histogram(I[:, :, channel_index])
22     cumulative_distr, cumulative_bins = exposure.cumulative_distribution(I[:, :, channel_index], nbins=256
23
24
25     plt.subplot(2, 3, channel_index + 2)
26     plt.plot(pixel_bins, hist_values, color='black', label=f'Histogram: {channels_lbls[channel_index]}')
27     plt.plot(cumulative_bins, cumulative_distr * hist_values.max(), color=channel_color, label=f'CDF: {cha
28
29
30     plt.title(f'{channels_lbls[channel_index]} - Histogram & CDF')
31     plt.xlabel("Pixel Value")
32     plt.ylabel("Count / CDF")
33     plt.legend(loc='best')
34
35
36 plt.tight_layout()
37 plt.show()
38
```

[]

Original RGB Image



```
<ipython-input-25-5014126435b9>:25: MatplotlibDeprecationWarning: Auto-removal of overlapping axes is deprecated  
plt.subplot(2, 3, channel_index + 2)
```




```
1 # Plot the Image and its histogram + cdf of the grayscale image I_gray  
2  
3 ### BEGIN SOLUTION  
4  
5 io.imshow(I_gray)  
6  
7 plt.figure(figsize=(10, 5))  
8 plt.subplot(1, 2, 1)  
9 plt.imshow(I_gray, cmap='gray')  
10 plt.title("Grayscale Image")  
11 plt.axis('off')  
12  
13 hist, hist_centers = exposure.histogram(I_gray)  
14  
15 cdf, cdf_bins = exposure.cumulative_distribution(I_gray, nbins=256)  
16  
17 plt.subplot(1, 2, 2)  
18 plt.plot(hist_centers, hist, color='black', label='Histogram')  
19 plt.plot(cdf_bins, cdf * hist.max(), color='red', label='CDF')
```


```

20 plt.title('Histogram and CDF – Grayscale Image')
21 plt.xlabel('Pixel Intensity')
22 plt.ylabel('Frequency / CDF')
23 plt.legend(loc='upper left')
24
25
26 plt.show()
27
28
29 ### END SOLUTION

```



Grayscale Image



```


1 # Plot the Image and its histogram + cdf of the degraded image I_degraded
2
3 ### BEGIN SOLUTION
4
5 io.imshow(I_degraded)
6
7 plt.figure(figsize=(10, 5))
8 plt.subplot(1, 2, 1)
9 plt.imshow(I_degraded, cmap = "gray")
10 plt.title("Degraded Image")
11 plt.axis('off')
12
13 hist, hist_centers = exposure.histogram(I_degraded)
14

```


```

15 cdf, cdf_bins = exposure.cumulative_distribution(I_degraded, nbins=256)
16
17 plt.subplot(1, 2, 2)
18 plt.plot(hist_centers, hist, color='black', label='Histogram')
19 plt.plot(cdf_bins, cdf * hist.max(), color='red', label='CDF')
20 plt.title('Histogram and CDF - Degraded Image')
21 plt.xlabel('Pixel Intensity')
22 plt.ylabel('Frequency / CDF')
23 plt.legend(loc='upper left')
24
25
26 plt.show()
27
28
29

```



Degraded Image



```


1 # Equalize the histogram of the degraded image I_degraded
2 # Save the result in I_recon_gray, display the image along with its histogram
3
4 I = io.imread("sample.jpeg")
5 I = I / 255.0
6
7 I_degraded = color.rgb2gray(I)
8
9 I_recon_gray = exposure.equalize_hist(I_degraded)

```

```

10
11 plt.figure(figsize=(10, 5))
12
13
14 plt.subplot(1, 2, 1)
15 plt.imshow(I_recon_gray, cmap='gray')
16 plt.title("Equalized Grayscale Image")
17 plt.axis('off')
18
19 hist, hist_centers = exposure.histogram(I_recon_gray)
20 cdf, cdf_bins = exposure.cumulative_distribution(I_recon_gray, nbins=256)
21
22 plt.subplot(1, 2, 2)
23 plt.plot(hist_centers, hist, color='black', label='Histogram')
24 plt.plot(cdf_bins, cdf * hist.max(), color='red', label='CDF')
25 plt.title('Histogram and CDF of Equalized Grayscale Image')
26 plt.xlabel('Pixel Intensity')
27 plt.ylabel('Frequency / CDF')
28 plt.legend()
29
30 plt.tight_layout()
31 plt.show()
32
33
34

```



```

1 # Equalize the histogram of the degraded image I_degraded using AHE
2 # Save the result in I_recon_gray_2, display the image along with its histogram
3
4 I_recon_gray_2 = exposure.equalize_adapthist(I_degraded) # Perform Adaptive Histogram Equalization (AHE)
5
6 plt.figure(figsize=(10, 5))
7
8
9 plt.subplot(1, 2, 1)
10 plt.imshow(I_recon_gray_2, cmap='gray')
11 plt.title("AHE Grayscale Image")
12 plt.axis('off')
13
14
15 hist, hist_centers = exposure.histogram(I_recon_gray_2)
16 cdf, cdf_bins = exposure.cumulative_distribution(I_recon_gray_2, nbins=256)
17
18 plt.subplot(1, 2, 2)
19 plt.plot(hist_centers, hist, color='black', label='Histogram')
20 plt.plot(cdf_bins, cdf * hist.max(), color='red', label='CDF')
21 plt.title('Histogram and CDF of AHE Grayscale Image')
22 plt.xlabel('Pixel Intensity')

```

```

23 plt.ylabel('Frequency / CDF')
24 plt.legend()
25
26 plt.tight_layout()
27 plt.show()


```



AHE Grayscale Image



Histogram and CDF of AHE Grayscale Image



```

1 # Equalize the histogram of the degraded image I_degraded using CLAHE
2 # Save the result in I_recon_gray_2, display the image along with its histogram
3
4 I_recon_gray_3 = exposure.equalize_adapthist(I_degraded, kernel_size=(36,36),clip_limit=0.01)
5
6
7 plt.figure(figsize=(10, 5))
8
9
10 plt.subplot(1, 2, 1)
11 plt.imshow(I_recon_gray_3, cmap='gray')
12 plt.title("CLAHE Grayscale Image")
13 plt.axis('off')
14
15
16 hist, hist_centers = exposure.histogram(I_recon_gray_3)
17 cdf, cdf_bins = exposure.cumulative_distribution(I_recon_gray_3, nbins=256)
18
19 plt.subplot(1, 2, 2)
20 plt.plot(hist_centers, hist, color='black', label='Histogram')
21 plt.plot(cdf_bins, cdf * hist.max(), color='red', label='CDF')
22 plt.title('Histogram and CDF of CLAHE Grayscale Image')
23 plt.xlabel('Pixel Intensity')
24 plt.ylabel('Frequency / CDF')
25 plt.legend()
26
27 plt.tight_layout()
28 plt.show()


```



CLAHE Grayscale Image




Histogram and CDF of CLAHE Grayscale Image



```
1 # Artificially degrade the original **RGB image** by reducing its contrast
2 # You can do so by rescaling the values of the L channel (in LAB color space)
3 # and concentrating them in a narrow range, say between 0.3 and 0.6.
4 # Save the image as I_rgb_degraded and display it
5 import numpy as np
6 import matplotlib.pyplot as plt
7 from skimage import io, color
8
9 I_lab = color.rgb2lab(I)
10
11 L_channel = I_lab[:, :, 0]
12
13 # Rescale the L channel values to the range [0.3, 0.6]
14 L_min, L_max = L_channel.min(), L_channel.max()
15 L_scaled = (L_channel - L_min) / (L_max - L_min)
16 L_degraded = L_scaled * (0.6 - 0.3) + 0.3
17
18
19 I_lab[:, :, 0] = L_degraded * 100
20
21 I_rgb_degraded = color.lab2rgb(I_lab)
22
23
24 plt.figure(figsize=(6, 6))
25 plt.imshow(I_rgb_degraded)
26 plt.title("RGB Image with Degraded Contrast (L Channel)")
27 plt.axis('off')
28 plt.show()
29
```

→ RGB Image with Degraded Contrast (L Channel)




```
1 # Equalize the histogram of the degraded color image I_rgb_degraded using CLAHE
2 # Save the result in I_recon_color, display the image along with its histogram
3 # HINT: You have to convert to LAB first
4 # See the lecture and lecture-4-demo-codes
5 import numpy as np
6 import matplotlib.pyplot as plt
7 from skimage import color, exposure, io
8
9 I = io.imread("sample.jpeg")
10 I = I / 255.0
11
12 I_lab = color.rgb2lab(I)
13
14 L = I_lab[:, :, 0]
15
16 L_normalized = (L - L.min()) / (L.max() - L.min())
17
18 # Apply CLAHE to the normalized L channel
19 L_clahe = exposure.equalize_adapthist(L_normalized, clip_limit=0.03)
20
21 L_clahe_rescaled = L_clahe * (L.max() - L.min()) + L.min()
22
23 I_lab_clahe = I_lab.copy()
24 I_lab_clahe[:, :, 0] = L_clahe_rescaled
25
26 I_recon_color = color.lab2rgb(I_lab_clahe) # Convert the LAB image back to RGB
27
28 plt.figure(figsize=(10, 5)) # Display the CLAHE-enhanced RGB image
29 plt.subplot(1, 2, 1)
30 plt.imshow(I_recon_color)
31 plt.title("CLAHE Enhanced RGB Image")
32 plt.axis('off')
33
34 I_gray = color.rgb2gray(I_recon_color)
35 hist, hist_centers = exposure.histogram(I_gray)
36 cdf, cdf_bins = exposure.cumulative_distribution(I_gray, nbins=256)
37
38 plt.subplot(1, 2, 2)
39 plt.plot(hist_centers, hist, color='black', label='Histogram')
40 plt.plot(cdf_bins, cdf * hist.max(), color='red', label='CDF')
41 plt.title('Histogram and CDF of CLAHE Enhanced RGB Image')
42 plt.xlabel('Pixel Intensity')
43 plt.ylabel('Frequency / CDF')
44 plt.legend()
45
46 plt.tight_layout()
```

```

47 plt.show()
48

```

→ <ipython-input-38-8cef76909196>:26: UserWarning: Conversion from CIE-LAB, via XYZ to sRGB color space resulted in I\_recon\_color = color.lab2rgb(I\_lab\_clahe) # Convert the LAB image back to RGB



## ▼ Task 3 - Open Ended

**There are 3 images in the drive directory below. Look at the questions from the brackets [ ]. Answer them in the provided text cell at the bottom.**

link: <https://drive.google.com/drive/folders/1ft3XrO-MGxhxL2PfcLCFQjU0wvILAv4?usp=sharing>

```

1 # Dark_Room.jpg = very dark [The windows are on walls. How does the wall look like?]
2 # Foggy_Road.jpg = washed out/foggy [How many vehicles do you think there are?]
3 # Read_the_code.jpg = Dark RGB Barcode [What is hidden in the Barcode?]
4 #                                     Make it scanable, scan it and say something about the hidden messa
5
6 # Your task is to improve these images using
7 # contrast stretching, histogram equalization, AHE or CLAHE
8 # try different combination of parameter settings to see which produces the best result
9
10 ### BEGIN SOLUTION
11
12 ### END SOLUTION

```

```



1 #Contrast Stretching
2
3 # Load the image
4 Dark_rgb = io.imread("Dark_Room.jpg")
5
6 Dark = color.rgb2gray(Dark_rgb)
7
8 # Stretch contrast
9 Dark_I_stretch = np.clip(4 * (Dark +0.2), 0, 1)
10
11 # Histogram equalization
12 Dark_I_eq = exposure.equalize_hist(Dark)
13
14 # Adaptive histogram equalization
15 Dark_I_adapt_eq = exposure.equalize_adapthist(Dark,kernel_size=(36,36),clip_limit=0.09)
16
17 # CLAHE (Contrast Limited Adaptive Histogram Equalization)

```

```

18 Dark_I_clahe = exposure.equalize_adapthist(Dark, kernel_size=(36,36), clip_limit=0.09)
19
20 ## Plot all images in one row
21 fig, axes = plt.subplots(2, 3, figsize=(15, 10))
22
23 # Original image
24 axes[0][0].imshow(Dark, cmap='gray')
25 axes[0][0].set_title("Original Image")
26 axes[0][0].axis('off')
27
28 # Contrast Stretched Image
29 axes[0][1].imshow(Dark_I_stretch, cmap='gray')
30 axes[0][1].set_title("Contrast Stretch")
31 axes[0][1].axis('off')
32
33 # Histogram Equalized Image
34 axes[0][2].imshow(Dark_I_eq, cmap='gray')
35 axes[0][2].set_title("Histogram Equalization")
36 axes[0][2].axis('off')
37
38 # Adaptive Histogram Equalization Image
39 axes[1][0].imshow(Dark_I_adapt_eq, cmap='gray')
40 axes[1][0].set_title("Adaptive Hist. Equalization")
41 axes[1][0].axis('off')
42
43 # CLAHE Image
44 axes[1][1].imshow(Dark_I_clahe, cmap='gray')
45 axes[1][1].set_title("CLAHE")
46 axes[1][1].axis('off')
47
48 # Show all images side by side
49 plt.tight_layout()
50 plt.show()
51
52
53
54

```



```


1 foggy_rgb = io.imread("Foggy_Road.jpg")
2 foggy = color.rgb2gray(foggy_rgb)
3 def plot_hist(I, nbins=256, normalize=False, plot_cdf=True):
4     hist, bins_hist = exposure.histogram(I.ravel(), nbins=nbins, normalize=normalize)

```

```

5     plt.plot(bins_hist, hist, 'k')
6     plt.xlabel("pixel values")
7     if normalize:
8         plt.ylabel("probability")
9     else:
10        plt.ylabel("count")
11    xmax = 1 if I.max() <= 1 else 255
12    plt.xlim([0, xmax])
13
14    if plot_cdf:
15        cdf, bins_cdf = exposure.cumulative_distribution(I.ravel(), nbins=nbins)
16        plt.twinx()
17        plt.plot(bins_cdf, cdf, 'r', lw=3)
18        plt.ylabel("percentage")
19
20
21 def plot_img_and_hist(I, nbins=256, normalize=False, plot_cdf=True, figsize=(12, 6)):
22
23     plt.subplot(2, 1, 2)
24     plot_hist(I, nbins=nbins, normalize=normalize, plot_cdf=plot_cdf)
25     plt.title("histogram")
26
27 plt.rcParams['figure.figsize'] = (6, 6)
28 plot_img_and_hist(foggy )


```



```

1
2 foggy_I_stretch = (foggy-.8)/(.9-.8)
3 io.imshow(foggy_I_stretch);

```



```


1 #Contrast Stretching
2
3 # Load the image
4 foggy_rgb = io.imread("Foggy_Road.jpg")
5 foggy = color.rgb2gray(foggy_rgb)
6
7
8 # Histogram equalization
9 foggy_I_eq = exposure.equalize_hist(foggy)
10
11 # Adaptive histogram equalization
12 foggy_I_adapt_eq = exposure.equalize_adapthist(foggy,kernel_size=(128, 128), clip_limit=0)

```

```

13
14 # CLAHE (Contrast Limited Adaptive Histogram Equalization)
15 foggy_I_clahe = exposure.equalize_adapthist(foggy, kernel_size=(128, 128), clip_limit=0.03)
16
17 # Plot all images in one row
18 fig, axes = plt.subplots(2, 3, figsize=(15, 10))
19
20 # Original image
21 axes[0][0].imshow(foggy, cmap='gray')
22 axes[0][0].set_title("Original Image")
23 axes[0][0].axis('off')
24
25 # Contrast Stretched Image
26 axes[0][1].imshow(foggy_I_stretch, cmap='gray')
27 axes[0][1].set_title("Contrast Stretch")
28 axes[0][1].axis('off')
29
30 # Histogram Equalized Image
31 axes[0][2].imshow(foggy_I_eq, cmap='gray')
32 axes[0][2].set_title("Histogram Equalization")
33 axes[0][2].axis('off')
34
35 # Adaptive Histogram Equalization Image
36 axes[1][0].imshow(foggy_I_adapt_eq, cmap='gray')
37 axes[1][0].set_title("Adaptive Hist. Equalization")
38 axes[1][0].axis('off')
39
40 # CLAHE Image
41 axes[1][1].imshow(foggy_I_clahe, cmap='gray')
42 axes[1][1].set_title("CLAHE")
43 axes[1][1].axis('off')
44
45 # Show all images side by side
46 plt.tight_layout()
47 plt.show()

```



```


1 #Contrast Stretching
2
3 # Load the image
4 code_rgb = io.imread("Read_the_code.jpg")
5 code = color.rgb2gray(code_rgb)
6

```

```

1
2 # Stretch contrast
3 Code_I_stretch = np.clip(4 * (code +0.2), 0, 1)
4
5 # Histogram equalization
6 Code_I_eq = exposure.equalize_hist(code)
7
8 # Adaptive histogram equalization
9 Code_I_adapt_eq = exposure.equalize_adapthist(code,kernel_size=(36, 36), clip_limit=0)
10
11 # CLAHE (Contrast Limited Adaptive Histogram Equalization)
12 Code_I_clahe = exposure.equalize_adapthist(code, kernel_size=(36, 36), clip_limit=0.01)
13
14 # Plot all images in one row
15 fig, axes = plt.subplots(1, 5, figsize=(15, 10))
16
17 # Original image
18 axes[0].imshow(code_I_adapt_eq, cmap='gray')
19 axes[0].set_title("Original Image")
20 axes[0].axis('off')
21
22 # Contrast Stretched Image
23 axes[1].imshow(Code_I_stretch, cmap='gray')
24 axes[1].set_title("Contrast Stretch")
25 axes[1].axis('off')
26
27 # Histogram Equalized Image
28 axes[2].imshow(Code_I_eq, cmap='gray')
29 axes[2].set_title("Histogram Equalization")
30 axes[2].axis('off')
31
32 # Adaptive Histogram Equalization Image
33 axes[3].imshow(Code_I_adapt_eq, cmap='gray')
34 axes[3].set_title("Adaptive Hist. Equalization")
35 axes[3].axis('off')
36
37 # CLAHE Image
38 axes[4].imshow(Code_I_clahe, cmap='gray')
39 axes[4].set_title("CLAHE")
40 axes[4].axis('off')
41
42 # Show all images side by side
43 plt.tight_layout()
44 plt.show()
45
46 # Show all images side by side
47 plt.tight_layout()
48 plt.show()

```



<Figure size 600x600 with 0 Axes>

#### ▼ Your answers:

- 1. Dark Image:** On the dark image, after using contrast stretching, histogram equalization, AHE and CLAHE we can almost clearly see that there are rectangular tiles all over the wall. CLAHE AHE gives the best result here. And, Histogram Equalization and Contrast Strething gives clear information about the flr that it is a wooden floor.
- 2. Foggy Image:** After applying the transformations we can see there are 7 bikes(clearly visible), 1 car in the middle and 2 car at the very right (not very visible). And one truck behind a car. In total there are 11 vehicles. Also, in this case CLAHE and AHE did a good job.

**3. Read the Code:** After applying contrast stretching, histogram equalization, AHE and CLAHE we can see that there is a QR Code and it is scanable. It redirected to document of Practise Sheet of CSE428: Image Processing. It will help us to have a strong grip on image processing. URL:[https://docs.google.com/document/d/1Y3Z\\_DvDcCJG9a0C4N4CMfX4KM5wGP-cxBekb8WT2cfg/edit?usp=drivesdk](https://docs.google.com/document/d/1Y3Z_DvDcCJG9a0C4N4CMfX4KM5wGP-cxBekb8WT2cfg/edit?usp=drivesdk)

1 Start coding or generate with AI.